

# **Ethernet Switch – Premium Line**

---

## **IE-SW-PL16M Series (Managed)**

### **Hardware Installation Guide**

**Fourth Edition, October 2012**  
**1243370000/03/10.12**

Please note:

This document, the **detailed manual** and any further product information - if available - can be downloaded at the internet link:

**<http://www.weidmueller.com/downloads>**

#### **Copyright Notice**

Copyright © 2012 Weidmüller Interface GmbH & Co. KG

All rights reserved.

Reproduction without permission is prohibited.

**Weidmüller** 

## Package Checklist


Your Ethernet Switch is shipped with the following items. If any of these items are missing or damaged, please contact your Weidmüller customer service for assistance.

- 1 Ethernet Switch IE-SW-PL16M
- Hardware Installation Guide
- CD-ROM with User's Manual and Windows Utility (option)
  - **Please download CD-ROM from Internet page**  
**<http://www.weidmueller.com/downloads>**
- RJ45 to DB9 Console port cable
- Protective caps for unused ports



## Optional Accessories

- **RM-KIT (19" rack mounting kit)**
- → More detailed information in datasheet


# Panel Views of IE-SW-PL16M-16TX



1. Grounding screw
2. Console port
3. Heat dissipation orifices
4. 6-pin terminal block for DI 1, DI 2, and PWR 2
5. 6-pin terminal block for PWR 1, Relay 1, and Relay 2
6. 10/100BaseT(X), ports 1 to 16
7. PWR 1: LED for power input 1
8. PWR 2: LED for power input 2
9. Fault LED
10. MSTR/HEAD LED
11. CPLR/TAIL LED
12. Label
13. TP port's 100 Mbps LED
14. TP port's 10 Mbps LED
15. Article Number
16. Screw hole for Wall Mounting Kit
17. DIN-Rail Kit




# Panel Views of IE-SW-PL16M-14TX-2SC/2ST




**NOTE:**  
The appearance of the switch  
IE-SW-PL16M-14TX-2ST is - apart  
from the optical connectors -  
identical to IE-SW-PL16M-14TX-2SC


- 1. Grounding screw
- 2. Console port
- 3. Heat dissipation orifices
- 4. 6-pin terminal block for DI 1, DI 2, and PWR 2
- 5. 6-pin terminal block for PWR1 Relay 1, and Relay 2



- 6. 10/100BaseT(X), ports 1 to 14
- 7. PWR 1: LED for power input 1
- 8. PWR 2: LED for power input 2
- 9. Fault LED
- 10. MSTR/HEAD LED
- 11. CPLR/TAIL LED
- 12. Label
- 13. TP port's 100 Mbps LED
- 14. TP port's 10 Mbps LED
- 15. Article Number
- 16. 100BaseFX Port 15
- 17. 100BaseFX Port 16
- 18. 100BaseFX LEDs
- 19. Screw hole for Wall Mounting Kit
- 20. DIN-Rail Kit



# Mounting Dimensions (unit = mm)




## DIN-Rail Mounting

The aluminum DIN-Rail attachment plate should already be fixed to the back panel of IE-SW-PL16M when you take it out of the box. If you need to reattach the DIN-Rail attachment plate to IE-SW-PL16M, make sure the stiff metal spring is situated towards the top, as shown by the following figures.

**STEP 1**—Insert the top of the DIN-Rail into the slot just below the stiff metal spring.

**STEP 2**—The DIN-Rail attachment unit will snap into place as shown in the following illustration.



To remove the IE-SW-PL16M switch from the DIN-Rail, simply reverse Steps 1 and 2 above.



## II 3G ATEX Information

1. Certification number DEMKO 11 ATEX 150191X
2. Ambient range ( $-40^{\circ}\text{C} \leq T_{\text{amb}} \leq 75^{\circ}\text{C}$ )
3. Certification string (Ex nC IIC T4)
4. Standards covered ( EN60079-0:2006, EN60079-15:2005)
5. The conditions of safe usage:



- The Ethernet Communication Devices are to be mounted in an IP54 enclosure and used in an area of not more than pollution degree 2 as defined by IEC60664-1.
- A 4mm<sup>2</sup> conductor must be used when connection to the external grounding screw is utilized.
- Conductors suitable for use in an ambient temperature of 93°C must be used for the Power Supply Terminal.
- Provisions shall be made, either in external to the apparatus, to prevent the rated voltage being exceeded by the transients disturbances of more than 40%.

## Wiring Requirements



### WARNING

Do not disconnect modules or wires unless power has been switched off or the area is known to be non-hazardous. The devices may only be connected to the supply voltage shown on the type plate. The devices are designed for operation with a Safety Extra-Low Voltage. Thus, they may only be connected to the supply voltage connections and to the signal contact with the Safety Extra-Low Voltages (SELV) in compliance with IEC950/EN60950/ VDE0805.



### ATTENTION

This unit is a built-in type. When the unit is installed in another piece of equipment, the equipment enclosing the unit must comply with fire enclosure regulation IEC 60950/EN60950 (or similar regulation).



### ATTENTION

#### Safety First!

Be sure to disconnect the power cord before installing and/or wiring your Ethernet Switch.

Calculate the maximum possible current in each power wire and common wire. Observe all electrical codes dictating the maximum current allowable for each wire size.

If the current goes above the maximum ratings, the wiring could overheat, causing serious damage to your equipment.

You should also pay attention to the following points:

- Use separate paths to route wiring for power and devices. If power wiring and device wiring paths must cross, make sure the wires are perpendicular at the intersection point
- NOTE: Do not run signal or communications wiring and power wiring through the same wire conduit. To avoid interference, wires with different signal characteristics should be routed separately
- You can use the type of signal transmitted through a wire to determine which wires should be kept separate. The rule of thumb is that wiring that shares similar electrical characteristics can be bundled together
- Separate input wiring and output wiring
- We advise that you label wiring to all devices in the system when necessary.

## Grounding the Ethernet Switch

Grounding and wire routing help limit the effects of noise due to electromagnetic interference (EMI). Run the ground connection from the ground screw to the grounding surface prior to connecting devices.




### ATTENTION

This product is intended to be mounted to a well-grounded mounting surface such as a metal panel.

## Wiring the Relay Contact

IE-SW-PL16M has two sets of relay outputs—relay 1 and relay 2. Each Relay Contact consists of the two contacts of the terminal block on IE-SW-PL16M top panel. You can refer to the next section for detailed instructions on how to connect the wires to the terminal block connector, and how to attach the terminal block connector to the terminal block receptor.

In this section, we will explain the meaning of the two contacts used to connect the Relay Contact.




### FAULT:

The two sets of relay contacts of the 6-pin terminal block connector are used to detect user-configured events. The two wires attached to the fault contacts form an open circuit when a user-configured event is triggered. If a user-configured event does not occur, the fault circuit remains closed.

## Wiring the Redundant Power Inputs

IE-SW-PL16M has two sets of power inputs—power input 1 and power input 2. The top two contacts and the bottom two contacts of the 6-pin terminal block connector on Ethernet Switch top panel are used for Ethernet Switch two digital inputs. The top and front views of one of the terminal block connectors are shown here.




**STEP 1:** Insert the negative/positive DC wires into the V-/V+ terminals, respectively.

**STEP 2:** To keep the DC wires from pulling loose, use a small flat-blade screwdriver to tighten the wire-clamp screws on the front of the terminal block connector.

**STEP 3:** Insert the plastic terminal block connector prongs into the terminal block receptor, which is located on the IE-SW-PL16M top panel.

## Wiring the Digital Inputs

IE-SW-PL16M has two sets of digital inputs, DI 1 and DI 2. Each DI consists of two contacts of the 6-pin terminal block connector on Ethernet Switch top panel, which are used for Ethernet Switch two DC inputs. The top and front views of one of the terminal block connectors are shown here.



**STEP 1:** Insert the negative (ground)/positive DI wires into the  $\perp$  /I1 terminals, respectively.

**STEP 2:** To keep the DI wires from pulling loose, use a small flat-blade screwdriver to tighten the wire-clamp screws on the front of the terminal block connector.

**STEP 3:** Insert the plastic terminal block connector prongs into the terminal block receptor, which is located on the IE-SW-PL16M top panel.

## Communication Connections

All models of IE-SW-PL16M have one RJ45 console port (RS-232 interface), between 14 and 16 10/100BaseTX Ethernet ports and 0 (zero) or 2 100BaseFX (SC/ST-type connector) fiber ports

In this section, we present two types of diagrams—Pinout Diagrams and Cable Wiring Diagrams—to convey information about the ports and the cables used to connect IE-SW-PL16M Series to other devices:

**Pinouts**—The meaning of the “Pinouts” diagrams is straightforward. The diagrams simply display the type of signal passing through each of the port’s pins.

**Cable Wiring**—Diagrams labeled “Cable Wiring” present standard cable wiring schemes for cables used to connect Ethernet Switch’s ports to other devices. These diagrams display three pieces of information:

1. When building your own cable, refer to the “pin-to-pin” Cable Wiring information displayed between the two vertical dashed lines to see which pin of the connector on the left should be connected to which pin of the connector on the right.
2. The information to the left of the left vertical dashed lines gives the pinouts of the relevant Ethernet Switch port.
3. The information to the right of the right vertical dashed line gives the pinouts of the opposing device’s port.


- NOTE**
1. The pin numbers for male DB9 and DB25 connectors, and hole numbers for female DB9 and DB25 connectors are labeled on the connector. However, the numbers are typically quite small, so you may need to use a magnifying glass to see the numbers clearly.
  2. The pin numbers for both 8-pin and 10-pin RJ45 connectors (and ports) are typically not labeled on the connector (or port). Refer to the following Pinout and Cable Wiring diagrams to see how RJ45 pins are numbered

## RS-232 Connection


IE-SW-PL16M Series has one RS-232 (10-pin RJ45) console port, located on the top panel. Use either an RJ45-to-DB9 or RJ45-to-DB25 cable (see the cable following wiring diagrams) to connect IE-SW-PL16M Series console port to your PC’s COM port. You may then use a console terminal program, such as Windows Hyper Terminal, to access IE-SW-PL16M Series console configuration utility.

### RJ45 (10-pin) Console Port Pinouts


Pin	Description
1	-----
2	DSR
3	-----
4	GND
5	TxD
6	RxD
7	GND
8	-----
9	DTR
10	-----



### RJ45 (10-pin) to DB9 (F) Cable Wiring



### RJ45 (10-pin) to DB25 (F) Cable Wiring




## 10/100BaseT(X) Ethernet Port Connection

The 10/100BaseT(X) ports located on Ethernet Switch's front panel are used to connect to Ethernet-enabled devices. Most users will choose to configure these ports for Auto MDI/MDI-X mode, in which case the port's pinouts are adjusted automatically depending on the type of Ethernet cable used (straight-through or cross-over), and the type of device (NIC-type or HUB/Switch-type) connected to the port.

In what follows, we give pinouts for both MDI (NIC-type) ports and MDI-X (HUB/Switch-type) ports. We also give cable wiring diagrams for straight-through and cross-over Ethernet cables.


### RJ45 (8-pin, MDI) Port Pinouts

Pin	Signal
1	Tx+
2	Tx-
3	Rx+
6	Rx-




### RJ45 (8-pin, MDI-X) Port Pinouts


Pin	Signal
1	Rx+
2	Rx-
3	Tx+
6	Tx-



### RJ45 (8-pin) to RJ45 (8-pin) Straight-through Cable Wiring



### RJ45 (8-pin) to RJ45 (8-pin) Cross-over Cable Wiring




## 100BaseFx Ethernet Port Connection

The concept behind the SC/ST port and cable is quite straightforward. Suppose you are connecting devices I and II. As opposed to electrical signals, optical signals do not require a circuit in order to transmit data. Consequently, one of the optical lines is used to transmit data from device I to device II, and the other optical line is used to transmit data from device II to device I, for full-duplex transmission.

Remember to connect the **Tx (transmit)** port of device I to the **Rx (receive)** port of device II, and the **Rx (receive)** port of device I to the **Tx (transmit)** port of device II.

**SC-Port Pinouts**



**ST-Port Pinouts**



**ATTENTION**

This is a Class 1 Laser/LED product. To prevent damage to your eyes, do not stare directly into the laser beam.

**LED Indicators**

The front panel of IE-SW-PL16M contains several LED indicators. The function of each LED is described in the following table:

LED	Color	State	Description
PWR1	AMBER	On	Power is being supplied to power input P1.
		Off	Power is <b>not</b> being supplied to power input P1.
PWR2	AMBER	On	Power is being supplied to power input P2.
		Off	Power is <b>not</b> being supplied to power input P2.
FAULT	RED	On	When the corresponding PORT alarm is enabled, and a user-configured event is triggered.
		Off	When the corresponding PORT alarm is enabled and a user-configured event is not triggered, or when the corresponding PORT alarm is disabled.
MSTR/HEAD	GREEN	On	When the switch is set as the Master of the Turbo Ring, or as the Head of the Turbo Chain.
		Blinking	The switch has become the Ring Master of the Turbo Ring, or the Head of the Turbo Chain, after the Turbo Ring or the Turbo Chain is down.
		Off	When the switch is not the Master of this Turbo Ring or is set as the Member of the Turbo Chain.

<b>CPLR/TAIL</b>	GREEN	On	When the switch coupling function is enabled to form a back-up path, or when it's set as the Tail of the Turbo Chain.
		Blinking	When the Turbo Chain is down.
		Off	When the switch disables the coupling function.
<b>10M (TP)</b>	GREEN	On	TP port's 10 Mbps link is active.
		Blinking	Data is being transmitted at 10 Mbps.
		Off	TP port's 10 Mbps link is inactive.
<b>100M (TP)</b>	GREEN	On	TP port's 100 Mbps link is active.
		Blinking	Data is being transmitted at 100 Mbps.
		Off	TP port's 100 Mbps link is inactive.

## Specifications

### Technology

Standards	IEEE 802.3 for 10BaseT, IEEE 802.3u for 100BaseT(X) and 100Base FX, IEEE 802.3x for Flow Control, IEEE 802.1D for Spanning Tree Protocol, IEEE 802.1w for Rapid STP, IEEE 802.1Q for VLAN Tagging, IEEE 802.1p for Class of Service, IEEE 802.1X for Authentication, IEEE 802.3ad for Port Trunk with LACP
Protocols	IGMPv1/v2, GMRP, GVRP, SNMPv1/v2c/v3, DHCP Server/Client, DHCP Option 66/67/82, BootP, TFTP, SNTP, SMTP, RARP, RMON, HTTP, HTTPS, Telnet, SSH, Syslog, IPv6, LLDP, IEEE 1588 PTP, Modbus/TCP, SNMP Inform
MIB	MIB-II, Ethernet-like MIB, P-BRIDGE MIB, Q-BRIDGE MIB, Bridge MIB, RSTP MIB, RMON MIB Group 1,2,3,9
<b>Interface</b>	
RJ45 Ports	10/100BaseT(X) auto negotiation speed, F/H duplex mode, and auto MDI/MDI-X connection
Fiber Ports	100BaseFX (SC/ST connector)
Console Port	RS-232 (10-pin RJ45)
LED Indicators	PWR1, PWR2, FAULT, 10/100M (TP port), MSTR/HEAD and CPLR/TAIL
Alarm Contact	Two relay outputs with current carrying capacity of 1A @ 24 VDC

Digital Input Two inputs with the same ground, but electrically isolated from the electronics

- For state "1": +13 to +30V
- For state "0": -30 to +3V
- Max. input current: 8 mA

**Power**

Input Voltage 24 VDC (12 to 45 VDC), redundant inputs

Input Current (@24V) IE-SW-PL16M-16TX: Max. 0.44A  
IE-SW-PL16M-14TX-2SC/ST: Max. 0.51A

Connection Two removable 6-pin terminal blocks

Overload Current Protection Present

Reverse Polarity Protection Present

**Mechanical**

Casing IP30 protection, metal case

Dimensions 95 × 135 × 140 mm (W × H × D)

Weight 1.586 kg

Installation DIN-Rail, Wall Mounting

**Environment**

Operating Temperature 0 to 60°C (32 to 140°F)  
-40 to 75°C (-40 to 167°F) for -T models

Storage Temperature -40 to 85°C (-40 to 185°F)

Ambient Relative Humidity 5% to 95% (non-condensing)

**Regulatory Approvals**

Safety UL 508, UL60950-1  
CSA C22.2 No. 60950-1, EN60950-1

Hazardous Location UL/cUL Class I, Division 2, Groups A, B, C, and D, ATEX, Zone 2, Ex nC IIC

EMI FCC Part 15, CISPR (EN55022) class A

EMS EN61000-4-2 (ESD), Level 2  
EN61000-4-3 (RS), Level 3  
EN61000-4-4 (EFT), Level 2  
EN61000-4-5 (Surge), Level 3  
EN61000-4-6 (CS), Level 3  
EN61000-4-8  
EN61000-4-11  
EN61000-4-12

Shock IEC60068-2-27

Freefall IEC60068-2-32

Vibration IEC60068-2-6

**WARRANTY**

5 years

Weidmüller gives a 5 year warranty on this product in accordance with the warranty terms as described in the general conditions of sale of the Weidmüller company which has sold the products to you. Weidmüller warrants to you that such products the defects of which have already existed at the time when the risk passed will be repaired by Weidmüller free of charge or that Weidmüller will provide a new, functionally equivalent product to replace the defective one. Where expressly described otherwise in writing in this catalogue/product description, Weidmüller gives no warranty or guarantee as to the interoperability in specific systems or as to the fitness for any particular purpose. To the extent permitted by law, any claims for damages and reimbursement of expenses, based on whatever legal reason, including contract or tort, shall be excluded. Where not expressly stated otherwise in this warranty, the general conditions of purchase and the expressive liability commitments therein of the respective Weidmüller company which has sold the products to you shall be applicable.

**Contact Information**

Weidmüller Interface GmbH & Co. KG  
Postfach 3030  
32760 Detmold  
Klingenbergstraße 16  
32758 Detmold  
Germany

Phone +49 (0) 5231 14-0  
Fax +49 (0) 5231 14-2083  
E-Mail [info@weidmueller.com](mailto:info@weidmueller.com)  
Internet [www.weidmueller.com](http://www.weidmueller.com)